

SYSTEM DESCRIPTION

ITEM	MODULE	P/N	DESCRIPTION
001	EVAC-2101-M	2101-M	Basic Zone-Selectable System in large cabinet (CAB-M) with one (1) Speaker circuit. Includes Battery Cable. Expansion: twenty (20) zones maximum in single cabinet. System may be expanded indefinitely using extension cabinets.
<p><i>Expansion of the EVAC-2101-M beyond Four (4) zones will be on a per quote basis and will not be broken down into components. Quotations will only be provided when completed systems worksheets are submitted.</i></p>			

Accessories are for adding functions and expanding system capabilities. Make sure that there is space within existing systems for any additional equipment.

ACCESSORIES / OPTIONAL MODULES: DESCRIPTIONS			
ITEM	MODULE	P/N	DESCRIPTION
002	AMP-SUPV	910515	Amplifier Supervisory Card (use when second amplifier is for standby / back-up power)
003	CAB-TRIM-M	910550-M	Semi-flush Trim (for Large Cabinet: CAB-M)
004	MM-1	910520	MessageMaker®: Pre-Recorded Message + Sequencer
005	MM-1-IC	18700330	MessageMaker Voice Chip: extends recording capability by sixty (60) seconds approximately.
006	RMT-PG-PA	910591	Remote Paging Unit. Pre-amplifier in cabinet.
007	SPKR-SUPV-1	910513	Speaker Supervisory Card: Single-Channel
008	SPKR-SUPV-2	910530	Speaker Supervisory Card: Dual-Channel
009	SPLT-MB-A	910512-A	Splitter Mother Board, Class A (Style Z) - to convert basic system to Class A
010	STRB-SUPV	910531	Strobe / Relay Supervisory Module
011	SUPV-RLY	910546	Relay with Supervised Output
012	SUPV-RLY-AUD	910581	Audio Relay Module (Remote Audio Pad)
013	SUPV-RLY-UNV	900882	Universal Relay Module: 24V DC; two (2) form 'C' contacts
014	SUPV-RLY-A	900883-A	Audio-Operated Relay (VOX)
015	T-GEN-S	900879-3	Pre-recorded Tone or Message Generator: Programmable

Please refer to "**EVAC-2101 Series • Price List**" for complete pricing information.
Item numbers on this Parts List correspond to item numbers on the Price List.

EXPANSION MODULES: DESCRIPTIONS			
<i>The following modules are for expanding an existing system: Consult worksheets and applications rules for systems expansion. Make sure that there is space within any existing system for any additional equipment.</i>			
<i>Please contact the factory for assistance.</i>			
ITEM	MODULE	P/N	DESCRIPTION
016	AMP-25-50	910510	50-Watt Amplifier: 25V or 70V (selectable) - for use with EVAC-2101
017	BATT-CBL	910467	Battery Cable
018	BATT-DIST	18300368	Battery Distribution Module
019	INTER-CAB HARNS	910529	Harnesses for connecting equipment between cabinets
020	CAB-M	910522	Medium/Large Cabinet
021	PS-AUX	910501	3.5A Regulated Auxiliary Power Supply - for use with EVAC-2101. Brown-out with transfer to battery. Earth-Ground detection.
022	SPKR-SUPV-1	910513	Speaker Supervisory Card: Single-Channel
023	SPKR-SUPV-2	910530	Speaker Supervisory Card: Dual-Channel
024	SPLT-MB-A	910512-A	Splitter Mother Board, Class A (Style Z)
025	SPLT-MB-B	910512-B	Splitter Mother Board, Class B (Style Y)
026	STRB-SUPV	910531	Strobe / Relay Supervisory Module
027	SUPV-RLY-A	900883-A	Audio-Operated Relay (VOX)
028	ZN-SWCD	910518	4-Zone Select Switchcard

REPLACEMENT MODULES: DESCRIPTIONS

The following modules are standard components of the basic system: and should be ordered as replacement parts only.

Please contact the factory for assistance.

ITEM	MODULE	P/N	DESCRIPTION
029	AMP-25-50	910510	50-Watt Amplifier: 25V or 70V (selectable)
030	AMP-CE	910506	Audio Common Equipment Card
031	C E	910503	System Common Equipment Card
032	CE-SWCD	910517	Common Equipment Switchcard
033	MM Select Harness	910559	MessageMaker Address Harness
034	PS-MAIN	910500	System (Main) Power Supply
035	SPLT-MB-B	910512-B	Splitter Mother Board, Class B (Style Y)

